

URC-39860 ADB Settop Star TV Remote

Power & Volume

- Start with the TV turned on.
- Press the **TV** on the remote.
- Press and hold down the **SHIFT** key until the red light blinks once and then twice.
- Press **991**. The red light will blink twice.

- Aim the remote at your television. Press the **CHANNEL UP** button (PROG+) over and over in order to scan through the codes available in the memory. You may have to press this key many times (up to 150 times) so please be patient. If you skip past a code, you can go to the previous code(s) by pressing the **CHANNEL DOWN** button (PROG-).
- When the television turns off, press the **SHIFT** key to store the code.
- Volume lock to TV
- Press and hold down the **SHIFT** key until the red light blinks once and then twice.
- Press **993**.
- Then press the **TV** key and the red light will blink twice.

