


R	1, 221, 223, 222, 224, 225, 9, 11, 13, 226, 12, 14, 2, 15, 15, 17, 18, 19, 20, 21, 26, 22, 23, 77, 24,
C	2, 3, 4, 5, 7, 8, 13, 14, 221, 223, 222, 33, 12, 16, 6, 9, 17, 32, 11, 15, 18, 226, 227, 231, 232, 52, 54, 230, 229, 56, 55, 16, 214, 23, 26, 29, 22, 25, 28, 19, 21, 24, 27, 31, 51, 53, 75, 57, 61, 59, 58, 62, 64, 65, 63, 68, 71, 67, 69, 78, 66, 73, 83, 120, 74, 80, 81, 77, 76, 71
L	1, 2, 18, 212, 18, 8, 9, 9, 211, 212, 18, 20, 3, 4, 10, 203, 3, 4, 5, 6, 6, 7, 209, 205, 205, 206, 207, 11, 13, 15, 16, 17, 11, 13, 31, 33, 34, 32, 34, 35, 37, 38, 36, 38, 41, 43, 42, 42




* PŘÍJÍMAČ PŘEPNUT NA VKV

TLAČÍTKOVÝ PŘEPÍNAČ P1-P10

TLAČÍTKO, OZNACENÍ	STISKNUTÍM TLAČÍTKA MĚNÍ SE SPOJENÍ TAKTO:	ROZPOJÍ SE
VYP. P10	—	3-5, 9-11,
GRAMO P9	9-10	5-6, 10-11,
DV P8	1-2, 4-5, 8-9, 10-11,	5-6,
SVII P7	1-2, 4-5, 8-9, 10-11,	5-6, 9-10,
FERRIT P6	4-5	5-6, 10-11,
SVI P5	1-2, 4-5, 8-9, 10-11,	5-6, 9-10,
KVII P4	1-2, 4-5, 8-9, 10-11,	5-6, 9-10,
KVI P3	1-2, 4-5, 8-9, 10-11,	5-6, 9-10,
ŠÍŘE PÁSMO P2	13-14, 16-17,	14-15, 17-18,
VKV P1	1-2, 4-5, 7-8, 10-11, 16-17,	2-3, 5-6, 11-12, 14-15, 17-18,

PATICE ELEKTRONEK



E1, E2, E7, E8, E9, E10, E11, E3, E4, E5, E6

26, 22, 23, 77, 24, 27, 36, 31, 28, 32, 35, 29, 25, 33, 34,	37, 39, 41, 81, 38, 42, 43, 47, 45, 78, 54, 55, 48, 46, 52, 51, 79, 53, 44, 49, 56, 82, 58,	64, 62, 61, 63, 59, 57, 65, 66, 67, 68, 73, 69, 72, 74, 83, 71,	75,	76,
3, 83, 120, 74, 80, 81, 77, 76, 79, 82, 85, 84, 86, 87,	91, 92, 88, 89, 118, 93, 94,	95, 115, 96, 97, 116, 99, 101, 98, 102, 103, 117,	104, 225, 106, 105,	36, 108, 119, 107, 109, 111, 112, 113, 114, 110,
41, 43, 42, 42, 44, 44', 42',			208, 60,	51, 51', 51'', 55, 56, 56', 57, 57', 52, 52', 58, 58', 59,

