

Service Bulletin 4812 715 40175

AUTHOR: Jochen Hohl

Last Update: 06/18/08

VERSION: 1.1

TITLE: Condensation water of Full glass ventilated door dropping on furniture

CAUSE


Condensation is on the inner glass of the FGVD. It could drop down on the furniture

REMEDIAL ACTION

Mount a bigger bottom trim under the door to collect the condensate and protect the furniture

During cooking of humid food there could occur condensation on the inner glass of the oven door. Normally this water is collected in the trim under the door. If the amount of water during normal cooking is too much, the trim can be changed with a bigger bottom trim to avoid water dropping on the furniture.

4812 460 68639	Inox
4812 460 68641	Black
4812 460 49894	White



After installing the new bottom trim the gap between trim and furniture could be not big enough, door is blocked or furniture scratched. In these few cases feet can be mounted under the oven to lift up the appliance.

Service Kit **4812 310 39226**: consisting 4 feet and 4 screws



foot under oven



bottom trim too near to furniture