


R	3,1,152,156,157,153, 158,9,11,13,15,154,15, 17,19,21,23, 37,35,39,33,41,31,25,43,29,45,27, 4,7, 49,51, 53,65,63,67,61,69,59, 71,57, 73,55,75,77,79, 99,81,97,83, 95,85, 93,87,91,89, 101,103,105,107,109,111,113,115,117, 119,121, 123, 125,127,129, 131,133, 135,137, 139,
R	24,6,150,151,8, 159,14,12,10,7,16,155, 24,22,20,18,36,38,34,40,32,42,14,126,30,44,28,46, 48,142,52,50,54,143,64,66,62,68,144,60,70,58,72,56,74,78,76,80, 82,100,145,148,146,84,98,86,96,88,94,90,92,147,105,104,102,108,116,112,110,78, 120,122,124, 128,126,130,134,132, 138,136, 140,
C	1,2, 34,5,6,50,52,49,51,55,56,78,9,10, 11,12, 45, 13,14, 15,16, 17,18, 46,19,21,22,20,23,25,26,24, 27,28, 47, 48,29,30,31,32, 35,36, 33,34,37,38,41,42,39,40, 43,53,44,54,



Zapojení nf stereofonního zesilovače AZS 175